

IMPORTANT! PLEASE READ.

IF YOU ARE NOT CAREFUL, YOU WILL BREAK THE EARS OFF OF YOUR CAM. APPLY LOCTITE TO THE CAM GEAR BOLTS AND TORQUE THEM TO 14 FT. LBS. WHEN INSTALLING THE COMPRESSION RELEASE, TORQUE THE SOCKET BOLT TO 18 FT. LBS. WHILE HOLDING THE CRANK SHAFT. IF YOU BREAK THE EARS, OR STRIP THE BOLT HOLES, THIS IS *NOT COVERED BY WEB CAMS WARRANTY.* (PAGE 9-27)



1815 MASSACHUSETTS AVE • RIVERSIDE • CALIFORNIA • 92507 • USA
PHONE 951.369.5144 • FAX 951.369.7266 • WWW.WEBCAMSHAFTS.COM